

PORTABLE PERFORMANCE PUPPET STAGE

Assembly Instructions

Puppet Expressions, LLC, Elyria, OH 44035

www.prestostage.com

Registered U.S. Patent D630266

Made in China

ATTENTION! READ ALL DIRECTIONS BEFORE STARTING

This puppet stage is not a toy. The stage is intended to be assembled, used, and disassembled by adults. CAUTION: Care must be taken when handling metal frame and curtain rod assemblies. Follow directions and keep fingers or objects away from the scissor areas of the frame (i.e. the connection points of the frame rods), or bodily injury or damage to the frame may occur. Do not climb on the stage's metal frame. Do not lean on the stage. Do not place items on top of the stage, only on the play-board. To increase stability, place sandbags on the metal bars at the base of the stage. To disassemble the stage, follow the assembly directions in reverse. Do not force the frame to collapse. Wiggle the frame gently to settle the framework.

Thank you for purchasing a PrestoStage portable performance stage. With proper care, your stage will give you long and satisfying service. In the unlikely event that your stage is damaged due to shipping, you must contact the seller within 3 days of receipt and you must keep the original packaging when filing a claim.

PrestoStage warrants the stage to be free from defects in materials and workmanship for a period of 90 days from the date of purchase. If within the warranty period the stage is determined to have defective materials or workmanship, PrestoStage will, without charge for parts, replace the stage or its defective parts subject to the terms and limitations as follows.

1. Determination of defects and subsequent action to repair or replace the stage or its defective parts is at the discretion of PrestoStage.
2. The warranty does not cover periodic maintenance, repair, or part replacement due to negligence, wear and tear, failure to follow assembly and disassembly instructions, or treatment inconsistent with normal use.
3. A dated sales receipt of the stage is required when requesting warranty service.
4. In certain cases, shipping charges may apply.

You should always contact the seller of your stage to resolve any problems associated with shipping. You may contact Puppet Expressions, LLC at 844-5PRESTO (773786) for warranty service.

CONTENTS OF DUFFLE BAG:



Drawstring bag:
(fabric cover, 2 curtains,
playboard, folding curtain rod,
2 L-shaped curtain rod extenders).



Folding metal
frame

TO START:



Lift the two loose metal
tubes (curtain rod holders)
upward and out of the way.



Pull metal frame
apart using an outward
and upward motion.



As the frame enlarges,
begin pushing the square
hubs together.



Grab a square hub on the
outside, and one on the
inside, and push together.



Once the frame is brought to
the correct height (6'), connect
the plastic hooks to secure it.